


[t] 800.413.8783 
805.494.0622 
E-mail: service@sdcsecurity.com 
801 Avenida Acaso, Camarillo, CA 93012 
PO Box 3670, Camarillo, CA 93011

## INSTALLATION INSTRUCTIONS LRFC1R FIRST CHOICE REQUEST-TO-EXIT SWITCH KIT MODELS: 3600 & 3700


Attach the switch assembly to the ELR unit with the supplied screws as shown.



## SWITCH SPECIFICATION

ORG - N/C YEL - N/O WHT - COM 5 AMP @ 125 VAC RESISTIVE

Route wires through the cable tie, along the side of the ELR and out.



Any suggestions or comments to this instruction or product are welcome. Please contact us through our website or email engineer@sdcsecurity.com